

SØREN PRIP BEIER

TRANSPORT PHENOMENA

DOWNLOAD FREE TEXTBOOKS AT
BOOKBOON.COM

Transport Phenomena

This text is written to all chemical engineering students who are participating in courses about transport processes and phenomena, chemical unit operations and all other chemical engineering courses in general.

This text gives an overview of the analogies between well known terms such as:

- Diffusivity, D
- Thermal conductivity, k
- Dynamic viscosity, μ
- Permeability, L_p
- Electrical conductance, $1/R$

These terms are associated with the transport of mass, energy, momentum, volume and electricity (electrical charges) respectively. Many analogies can be extruded from these different phenomena which should be clear by reading this text. Since knowledge about transport phenomena in general is essential to a chemical engineer, understanding of these analogies can be very useful and to great help when solving all kinds of problems related to this topic.

September 2006
Søren Prip Beier


Please click the advert

WHAT'S MISSING IN THIS EQUATION?

You could be one of our future talents

MAERSK INTERNATIONAL TECHNOLOGY & SCIENCE PROGRAMME

Are you about to graduate as an **engineer** or **geoscientist**? Or have you already graduated?
If so, there may be an exciting future for you with A.P. Moller - Maersk.



MAERSK

www.maersk.com/mitas

1. Introduction

Things only move when they are forced to move! A bicycle only moves when a force is applied in the form of pedaling. A cloud on the sky only moves when a force is applied in the form of a storm or a wind. A soccer ball only flies into the goal net when a force in the form of a beautiful and precise shot from Peter Møller or another great soccer player is applied. Thus all sorts of transport only take place when a force, called a *driving force*, is applied. This is also the case when we are talking about transport of other things than bicycles, clouds and soccer balls.

Transport of mass, energy, momentum, volume and electricity only takes place when a driving force is applied. Transport can generally be expressed as a flux “ J ”, which is given by the amount of mass, energy, momentum, volume or charges that are transported pr. area pr. time. The transported amount is proportional to the applied driving force, which can be expressed by a linear phenomenological equation of the following kind:

$$J = -A \cdot \frac{dX}{dx} \quad (1)$$

The transport direction in this case is in the x-direction. In this text we are only dealing with the one-dimensional case. Analogies to two- and three dimensional cases can be found in teaching books about transport phenomena. The driving force is expressed as the gradient of X (concentration, temperature, velocity, pressure or voltage) along an x-axis parallel to the transport direction. Since transport always goes “downhill” from areas of high concentration, temperature, velocity etc. to areas of low concentration, temperature, velocity etc., a minus-sign is placed on the right side of the equation because the flux should be positive when the gradient dX/dx is negative. The proportionality constant A is called a phenomenological coefficient and is related to many well known physical terms associated with different kinds of transport. Table 1 lists different kinds transport together with the driving forces, phenomenological flux equations, names of the phenomenological coefficients, units of the different fluxes and the common name for the transport phenomena.

Table 1: Different kinds of transport

Driving forces are specified and flux equations are given for different kinds of transport. SI units for the phenomenological coefficients and the fluxes are given as well together with the common names for the different transport phenomena.

Transport Of	Driving Force	Flux Equation	Phenomenological Coefficient	Flux Unit	Common Name
Mass	Concentration gradient	$J_m = -D \cdot \frac{dc}{dx}$	Diffusion coefficient D [m^2/s]	$\left[\frac{kg}{m^2 \cdot s} \right]$	Fick's law of diffusion
Energy/heat	Temperature gradient	$J_h = -k \cdot \frac{dT}{dx}$	Thermal conductivity k [$J/(s \cdot K \cdot m)$]	$\left[\frac{J}{m^2 \cdot s} \right]$	Fourier's law of heat conduction
Momentum	Velocity gradient	$J_n = -\mu \cdot \frac{dv}{dx}$	Dynamic viscosity μ [$Pa \cdot s$]	$\left[\frac{kg \cdot (m/s)}{m^2 \cdot s} \right]$	Newton's law of viscosity
Volume	Pressure gradient	$J_v = -L_p \cdot \frac{dP}{dx}$	Permeability coefficient L_p [$m^2/(Pa \cdot s)$]	$\left[\frac{m^3}{m^2 \cdot s} \right]$	Darcy's law
Electrical	Voltage gradient	$J_e = -\sigma \cdot \frac{dE}{dx}$	Electrical conductance σ [$C^2/(s \cdot J \cdot m)$]	$\left[\frac{C}{m^2 \cdot s} \right]$	Ohm's law

2. Different kinds of transport

In the following sub sections the different kinds of transport listed in Table 1 will be described.

2.1 Diffusivity, Transport of mass

Diffusion of mass is also known as *mass diffusion*, *concentration diffusion* or *ordinary diffusion*. We are talking about molecular mass transport taking place as diffusion of a component A through a medium consisting of component B . The *diffusion coefficient* D_{AB} determines how fast the diffusion takes place. The subscript of the diffusion coefficient tells that the diffusion is associated with the diffusion of A through B . A diffusion situation is sketched in Figure 1 for the diffusion of a gas component A through a plate of silicone rubber.



Please click the advert

CHALLENGE YOURSELF

WWW.STUDYINSWEDEN.SE

Today's job market values ambitious, innovative, perceptive team players. Swedish universities foster these qualities through a forward-thinking culture where you're close to the latest ideas and global trends.

Whatever your career goals may be, studying in Sweden will give you valuable skills and a competitive advantage for your future. www.studyinsweden.se

SI.
Swedish Institute




Figure 1: Build-up of concentration profile in a silicone rubber plate

(a) The concentration of A at both sides of the silicone rubber plate is zero. (b) At $t = 0$ the concentration on the left side of the silicone rubber plate is increased to c_{A0} . (c) Component A starts to diffuse through the silicone rubber. At small values of t , the concentration of A in the silicone rubber is thus a function of both time and distance x . (d) At large values of t , steady state have been established and a linear concentration profile is reached. Thus at steady state the concentration of A is only a function of the distance x in the silicone rubber plate.

The blue boxes symbolize a barrier consisting of a plate of silicone rubber. The left and right sides are completely separated by the plate. The silicone rubber plate is assumed to consist of component B . Initially the concentration of component A is zero at both sides of the plate. At time $t = 0$ the concentration of A at the left side is suddenly raised to c_{A0} at which it is held constant. Component A starts to diffuse through B because of the driving force that exists in the form of a concentration difference. Thus the concentration of A increases in the silicone rubber as a function of the distance x inside the rubber and the time t . The concentration of A at the right side is kept at zero by continually removing the amount of A that has diffused through the silicone rubber. At large values of t , a steady state linear concentration profile has been reached. At this stage the concentration of A is only a function of the distance x inside the silicone rubber plate.

At steady state the flux of component A through the silicone rubber is given by the flux equation from Table 1, which is called *Fick's law of diffusion*:

$$J_A = -D_{AB} \cdot \frac{dc_A}{dx} \quad (2)$$

The flux J_A is the diffusive flux of component A in the direction x through the silicone rubber plate. The gradient dc_A/dx is the concentration gradient of component A inside the rubber plate which is the driving force. D_{AB} is as mentioned earlier the diffusion coefficient of A in B . The

value of the diffusion coefficient D_{AB} determines how fast the linear steady state concentration profile develops:

The larger the diffusion coefficient D_{AB} is, the faster the linear steady state concentration profile is reached. If D_{AB} is small, the flux of A is small and the time before steady state is reached is large.

The diffusion coefficient has the units of length² pr. time:

$$D, \quad SI - units : \left[\frac{m^2}{s} \right]$$

At constant temperatures and constant low pressures the diffusion coefficient for a binary gas mixture is almost independent of the composition and can thus be considered a constant. It is inversely proportional to the pressure and increases with the temperature. For binary liquid mixtures and for high pressures the behavior of the diffusion coefficient is more complicated and will not be discussed in this text.

2.2 Thermal conductivity, Transport of energy

Energy in the form of heat can be transported when a driving force in the form of a temperature difference is applied. The flux of heat is proportional to the applied driving force and the proportionality constant is called the *thermal conductivity* k . We are talking about molecular energy transport, and a situation with transport of heat through a one layer window is sketched in Figure 2.




Figure 2: Build-up of temperature profile in a window

(a) The temperature on both sides of the window is zero. (b) At $t = 0$ the temperature on the left side of the window is increased to T_0 . (c) Energy/heat starts to flow through the window. At small values of t , the temperature in the window is thus a function of both time and distance x in the window. (d) At large values of t , steady state is established and a linear temperature profile in the window is reached. Thus at steady state the temperature is only a function of the distance x in the window.



Initially the temperature on both sides of the window is zero (or room temperature) which means that no heat flow through the window. Suddenly at $t = 0$ the temperature on the left side of the window is increased to T_0 . Because of the temperature difference between the two sides of the window heat starts to flow through the window from the warm side to the cold side. The temperature on the right side is kept at zero. Before steady state is reached the temperature in the window is a function of both distance x and time t . Dependent of how good or bad an isolator the window is, a linear steady state temperature profile is reached after a period of time.

At steady state the flux of heat/energy through the window is given by the flux equation from Table 1, which is called *Fourier's law of heat conduction*:

$$J_h = -k \cdot \frac{dT}{dx} \quad (3)$$

The flux J_h is the flux of heat/energy in the direction x through the window. The gradient dT/dx is the temperature gradient which is the driving force. The term k is as mentioned earlier the thermal conductivity of the window. The value of the thermal conductivity together with other factors determines how fast the linear steady state temperature profile develops. These other factors are the density ρ and the heat capacity C_p of the window. The thermal conductivity, the density and the heat capacity can together be expressed at *the thermal diffusivity* α :

$$\alpha = \frac{k}{\rho \cdot C_p}, \quad SI - units : \left[\frac{J}{s \cdot K \cdot m} \cdot \frac{m^3}{kg} \cdot \frac{kg \cdot K}{J} \right] = \left[\frac{m^2}{s} \right] \quad (4)$$

It is seen from equation (4) that the thermal diffusivity has the same units as the ordinary diffusivity D (see section 2.1 *Diffusivity, Transport of mass*). Thus the thermal diffusivity can be thought of a diffusion coefficient for energy/heat. The thermal diffusivity of the window thus determines how fast the steady state temperature profile is established:

The larger the thermal diffusivity α (of the window) is, the faster the linear steady state temperature profile is reached. If α is small, the flux of heat/energy is small and the time before steady state is reached is large.

The thermal conductivity of gasses is of course dependent on the pressure but also on the temperature. Thermal conductivities of liquids and solids are also temperature dependent but almost pressure independent in the pressure range where they are almost incompressible. Further discussion about pressure and temperature dependence will not be given in this text.

2.3 Viscosity, Transport of momentum

Momentum can be transferred when a driving force in the form of a velocity difference exists. This can be explained by describing the situation sketched in Figure 3, which shows an example of molecular momentum transport.




Figure 3: Build-up of velocity profile in a Newtonian fluid

One plate to the left and one plate to the right are separated by a Newtonian. (a) The velocity of both plates is zero. (b) At $t = 0$ the left plate is set at motion with a constant velocity v_0 while the right plate is kept at rest (c) The fluid just next to the moving plate start to move. This fluid in motion then starts to move the fluid to the right which is at rest. Thus as the velocity is propagated, momentum is transferred in the x direction. At small values of t , the velocity in the fluid between the plates is a function of both time and distance x . (d) At large values of t , steady state is established and a linear velocity profile in the fluid is reached. Thus at steady state the velocity is only a function of the distance x in the fluid.

A Newtonian fluid (the term Newtonian will be explained in a moment) is contained between two plates. It could be water or ethanol for example. Initially the plates and the fluid are at rest. At time $t = 0$ the plate to the left is suddenly set at motion with a constant velocity v_0 in the y -direction. The fluid just next to the left plate will then also start to move in the y -direction. That way the fluid throughout the whole distance between the plates will eventually be set at motion. The right plate is kept at rest. The fluid just next to the right plate will all the time not move because “no slip” is assumed between the fluid and the plate. At small values of t the velocity in the y -direction is a function of both the time and distance x in the fluid. After a while a linear steady state velocity profile is established and thus the velocity in the y -direction is only a function of the distance x in the fluid.

A constant force is required to keep the left plate at motion. This force is proportional to the velocity v_0 , the area of the plate and inversely proportional to the distance between the two

plates. The *force pr. area* ration can be thought of as a flux of y -momentum (momentum in the y -direction) in the x -direction. The proportionality constant is the *dynamic viscosity* μ of the fluid (the dynamic viscosity can also be denoted with the symbol η). The viscosity of a fluid is then associated with a resistance towards flow.

At steady state the momentum flux (force in y -direction pr. area) through the fluid is given by the flux equation from Table 1, which is called *Newton's law of viscosity*:

$$J_n = -\mu \cdot \frac{dv}{dx} \quad (5)$$

Equation (5) only applies to fluids with molecular weights less than about 5000. Such fluids are called *Newtonian fluids* because they are described by Newton's law of viscosity. The viscosity of such fluids is independent of the velocity gradient which is not the case for non-Newtonian fluids.

Please click the advert



CHALLENGE YOURSELF

WWW.STUDYINSWEDEN.SE

Today's job market values ambitious, innovative, perceptive team players. Swedish universities foster these qualities through a forward-thinking culture where you're close to the latest ideas and global trends.

Whatever your career goals may be, studying in Sweden will give you valuable skills and a competitive advantage for your future. www.studyinsweden.se

SI.
Swedish Institute

The flux J_n is the flux of y -momentum in the direction x through the fluid. The gradient dv/dx is the velocity gradient which is the driving force. Remember that the velocity is in the y -direction and the momentum flux is in the x -direction. This gradient is often referred to as the *shear rate*. The term μ is as mentioned earlier the dynamic viscosity of the fluid. The value of the dynamic viscosity together with density of the fluid determines how fast the linear steady state velocity profile develops. The dynamic viscosity and the density of the fluid can together be expressed at the *kinematic viscosity* ν :

$$\nu = \frac{\mu}{\rho}, \quad SI - units : \quad \left[Pa \cdot s \cdot \frac{m^3}{kg} \right] = \left[\frac{kg}{m \cdot s} \cdot \frac{m^3}{kg} \right] = \left[\frac{m^2}{s} \right] \quad (6)$$

It is seen from equation (6) that the kinematic viscosity has the same units as the ordinary diffusivity D (see section 2.1 *Diffusivity, Transport of mass*) and the thermal diffusivity α (see section 2.2 *Thermal conductivity, Transport of energy*). Thus the kinematic viscosity can be thought of a diffusion coefficient for velocity. The kinematic viscosity of the fluid thus determines how fast the steady state velocity profile is established:

The larger the kinematic viscosity ν (of the fluid) is, the faster the linear steady state velocity profile is reached. If ν is small, the flux of momentum is small and the time before steady state is reached is large.

The dynamic viscosity is very temperature and pressure dependent. For liquids the dynamic viscosity decreases with increasing temperature while for low density gasses the viscosity increases with increasing temperature. The dynamic viscosity normally increases with increasing pressure. Further temperature and pressure dependency will not be given in this text.

2.4 Permeability, Transport of volume

A volume flux is induced when a driving force in the form of a pressure difference is applied. The flux of volume is proportional to this driving force and the proportionality constant is called the *permeability* L_p . This is often used in pressure driven membrane processes where a pressure difference across a membrane induces a volume flux through the membrane. Proportionality between the applied pressure and the flux is seen when pure water permeates through the membrane. A pressure difference situation across a membrane is sketched in Figure 4.




Figure 4: Build-up of pressure profile in a membrane

(a) The pressure on both sides of the membrane is zero. (b) At $t = 0$ the pressure on the left side of the membrane is increased to P_0 . (c) Water starts to flow through the membrane because of the pressure difference. Thus at very small t values, the pressure profile is not fully established. At this stage the pressure inside the membrane is a function of the distance x and the time t . (d) Very short after the pressure on the left side has been raised to P_0 , steady state is reached and a linear pressure profile in the membrane is achieved. Thus at steady state the pressure is only a function of the distance x inside the membrane.

Initially the pressure is zero (atmospheric pressure) at both sides of the membrane. No water will then flow through the membrane. At time $t = 0$ the pressure on the left side is suddenly raised to P_0 at which it is held constant. Water starts to flow through the membrane because of the pressure difference. The pressure thus increases in the membrane as a function of the distance x and the time t . The pressure on the right side is kept at zero. Because membranes are usually very thin, a steady state linear pressure profile is reached very fast, and thus the pressure is only a function of the distance x inside the membrane.

At steady state the volume flux through the membrane is given by the flux equation from Table 1, which is often called *Darcy's law*:

$$J_v = -L_p \cdot \frac{dP}{dx} \quad (7)$$

The flux J_v is the flux of volume in the direction x through the membrane. The gradient dP/dx is the pressure gradient inside the membrane which is the driving force. L_p is as mentioned earlier the permeability coefficient which depends on the resistance towards mass transport in the membrane (the membrane resistance) and the dynamic viscosity of the fluid that flows through the membrane. The resistance inside the membrane depends on many parameters such as pore size distribution, pore radius, tortuosity of the pores, hydrophilic/hydrophobic nature of the membrane material compared to the fluid etc. The permeability depends on the temperature

since the dynamic viscosity is a function of the temperature, and the pressure dependence of the permeability can also play a role if the membrane material is compressible.

2.5 Conductance, Transport of electricity

A flux of charges is induced when a driving force in the form of an electrical field is applied over a medium or a material that is able to conduct electrical charges. An electrical field has the unit of [V/m] corresponds to a voltage drop over a given length. In a wire the electrical flux consists of moving electrons, and the flux multiplied by the cross sectional area of the wire corresponds to the current measured in amperes [A]. The build-up of a voltage profile in a tin plate is sketched in Figure 5.

Please click the advert

Turning a challenge into a learning curve. Just another day at the office for a high performer.

Accenture Boot Camp – your toughest test yet

Choose Accenture for a career where the variety of opportunities and challenges allows you to make a difference every day. A place where you can develop your potential and grow professionally, working alongside talented colleagues. The only place where you can learn from our unrivalled experience, while helping our global clients achieve high performance. If this is your idea of a typical working day, then Accenture is the place to be.

It all starts at Boot Camp. It's 48 hours that will stimulate your mind and enhance your career prospects. You'll spend time with other students, top Accenture Consultants and special guests. An inspirational two days

packed with intellectual challenges and activities designed to let you discover what it really means to be a high performer in business. We can't tell you everything about Boot Camp, but expect a fast-paced, exhilarating

and intense learning experience. It could be your toughest test yet, which is exactly what will make it your biggest opportunity.

Find out more and apply online.

Visit [accenture.com/bootcamp](https://www.accenture.com/bootcamp)

• Consulting • Technology • Outsourcing


High performance. Delivered.




Figure 5: Build-up of voltage profile in a tin plate

(a) The voltage on both sides of the tin plate is zero. (b) At $t = 0$ the voltage on the left side of the tin plate is increased to E_0 while the voltage on the right side is kept a zero. (c) Electrical charges (electrons) start to flow through the tin plate because they are in an electrical field. At very, very small values of t , the voltage in the tin plate is a function of both time and distance x . (d) Very fast after the voltage on the left side is increased, steady state is reached and a linear voltage profile in the tin plate is established. Thus at steady state the voltage is only a function of the distance x in the tin plate.

Initially the voltage (energy pr. charge) is zero at both sides of the tin plate. No charges will then migrate through the tin plate. At time $t = 0$ the voltage on the left side is suddenly raised to E_0 at which it is held constant. Charges (electrons) start to migrate through the tin plate because of the voltage difference. The voltage on the right side is kept at zero. The voltage thus increases in the plate as a function of the distance x and the time t . Because tin is an electrical conductor, a steady state linear voltage profile through the plate is reached very fast, and thus the voltage is only a function of the distance x inside the tin plate after a very short period of time.

At steady state the electrical flux (current density) through the membrane is given by the flux equation from Table 1, which is called *Ohm's law*:

$$J_e = -\sigma \cdot \frac{dE}{dx} \quad (8)$$

The flux J_e is the flux of charges in the direction x through the tin plate. The gradient dE/dx , which is the voltage gradient inside the tin plate, is the driving force and is often called the electrical field. The electrical field can be explained as the effect that is produced by an electrical charge that exerts a force on charges objects in the field. The conductance σ of the tin plate is inversely proportional to the electrical resistivity of the tin plate. The resistivity tells how much the material or medium opposes the flow of the electrical current.

For a typical metal the resistivity normally increases linearly with the temperature which means that the electrical conductance decreases with the temperature.

3. Dimensionless numbers

In this section the first three transport phenomena (mass, energy and momentum) will be included in the explanation of different dimensionless numbers. For those three transport phenomena certain “diffusion coefficients” are able to describe how “easy” the transport takes place:

- *Ordinary diffusion coefficient*, D [m^2/s]: Tells how “easy” transport of mass takes place as diffusion of a component A through a fluid of component B .
- *Thermal diffusivity*, α [m^2/s]: Tell how “easy” transport of energy/heat takes place as “diffusion” of “joules” through a fluid.
- *Kinematic viscosity*, ν [m^2/s]: Tells how “easy” transport of momentum takes place as “diffusion” of velocity though a fluid.

Since these terms all have the same units [m^2/s] they can be used calculate certain dimensionless numbers describing properties of different fluids. These dimensionless numbers and their physical meaning are summed up in Table 2.

Please click the advert





it's an **interesting** world

Get under the skin of it.

Graduate opportunities
Cheltenham | £24,945 + benefits

One of the UK's intelligence services, GCHQ's role is two-fold: to gather and analyse intelligence which helps shape Britain's response to global events, and, to provide technical advice for the protection of Government communication and information systems. In doing so, our specialists – in IT, internet, engineering, languages, information assurance, mathematics and intelligence – get well beneath the surface of global affairs. If you thought the world was an interesting place, you really ought to explore our world of work.

www.careersinbritishintelligence.co.uk

Applicants must be British citizens. GCHQ values diversity and welcomes applicants from all sections of the community. We want our workforce to reflect the diversity of our work.








Table 2: Dimensionless numbers

Definitions and physical meanings of the dimensionless numbers.

Dimensionless number	Definition	Physical meaning
Lewis number	$Le = \frac{\alpha}{D_{AB}}$	The Lewis number tells how fast energy/heat propagates through the fluid compared to how fast mass (component <i>A</i>) propagates (diffuses) through the fluid (component <i>B</i>).
Schmidt number	$Sc = \frac{\nu}{D_{AB}}$	The Schmidt number tells how fast velocity propagates through the fluid compared to how fast mass (component <i>A</i>) propagates (diffuses) through the fluid (component <i>B</i>).
Prandtl number	$Pr = \frac{\nu}{\alpha}$	The Prandtl number tells how fast velocity propagates through the fluid compared to how fast energy propagates through the fluid.

The dimensionless numbers in Table 2 can be used in different dimensionless equations for describing systems in which competing transport processes occur.

4. Summary

In this text it has been shown that different kinds of transports (mass, energy, momentum, volume and electrical charges) can be described by phenomenological equations of the same kind. The flux is in all cases proportional to the driving force which is the gradient of concentration, temperature, velocity, pressure or voltage respectively. The proportionality constant is called a phenomenological coefficient and corresponds to well known physical properties such as the diffusion coefficient, thermal diffusivity, dynamic viscosity, permeability or electrical conductance for the different kinds of transport.

For the transport of energy and momentum, the ease at which the transport takes place, not only depends on the phenomenological coefficient but also on other physical properties such as heat capacity and density. By combining these terms with the phenomenological coefficient, the thermal diffusivity and the kinematic viscosity are defined. These terms have the same units as the ordinary diffusion coefficient and can thus be used in the comparison between competing transport processes in fluids. For this purpose three dimensionless numbers (Lewis number, Schmidt number and Prandtl number) are defined as the different ratios between the ordinary diffusion coefficient, the thermal diffusivity and the kinematic viscosity which are associated with the molecular transport of mass, energy and momentum respectively. These numbers can thus be used in dimensionless equations describing systems in which competing transport processes occur.